esatto


Ready to cook up a storm? Let's get started using this little Quick Start Guide to begin cooking with your ECC604K 60cm Ceramic Cooktop!



esatto

Get ready to use your ECC604K 60cm Ceramic Cooktop!

Your Cooktop



- A Durable Ceramic Glass
- B Max. 1800W zone
- C Max. 1200W zone
- D Max. 1800W zone
- E Max. 1200W zone
- F Control Panel

Get in Touch

Need help? Contact our friendly support team via the contact details below.

Phone / 1300 11 4357 Email / support@residentiagroup.com.au

Product Details

Dimensions (W, D, H mm) / 590 × 520 × 55 Cut-out (A, B mm) / 560 × 490 Warranty / 2 Years

Register your Esatto product online for a free additional year **esatto.house/warranty**

Before First Use

Before using your new Ceramic cooktop:

- Read all instructions in your user manual, particularly the 'Safety Instructions' section.
- Remove any protective film or stickers that may still be on your ceramic cooktop.
- You should perform a 'burn off': With a half filled saucepan of cold water, heat on one cooking zone at a time, for 5 minutes, at the maximum setting. This will help to eliminate any new smells that exists and evaporate any humidity that has formed on the heating elements during transit.

Operating Instructions

To start cooking:

- Place a suitable pan on the cooking zone that you wish to use. Make sure the bottom of the pan and the surface of the cooking zone are clean and dry.
- Turn the knob control clockwise to set your desired cooking level from 1–9. You can modify the heat setting at any time during cooking.

To finish cooking:

- Turn the cooking zone off by turning the knob counter-clockwise to the "OFF" position.
- After a zone is switched off, the residual heat indicator of the corresponding zone will be lit.
- The residual heat also can be used as an energy saving function if you want to heat further pans, use the hotplate that is still hot.

We're on Socials!

🞯 @esatto.house 📫 @esatto.house

www.esatto.house