

esatto


Ready to cook up a storm? Let's get started using this little Quick Start Guide to begin cooking with your **ECC604T** 60cm Ceramic Cooktop!



esatto

Get ready to use your ECC604T 60cm Ceramic Cooktop!

Your Cooktop



- A Durable Ceramic Glass
- B Max. 1800W zone
- C Max. 1200W zone
- D Max. 1800W zone
- E Max. 1200W zone
- F Touch Control Panel

Get in Touch

Need help? Contact our friendly support team via the contact details below.

Phone / 1300 11 4357

Email / support@residentiagroup.com.au

Product Details


Dimensions (W, D, H mm) / 590 x 520 x 55

Cut-out (A, B mm) / 560 x 490

Warranty / 2 Years

Register your Esatto product online for a free additional year esatto.house/warranty

Control Panel



- 1 Child lock button
- 2 Power regulating controls
- 3 Timer regulating controls
- 4 Zone indicators
- 5 Timer button
- 6 Power button

Operating Instructions



To start cooking:

- Touch the Power buttons and all indicators will display “-” and place a suitable pan on the cooking zone that you wish to use.
- Using the power regulating controls, select a heat setting on the relevant cooktop.

To finish cooking:

- Turn the cooking zone off by powering the regulating controls to “0”, or by pressing “-” & “+” together.
- Alternatively, turn the whole cooktop off by touching the Power button.
- After a zone is switched off, the residual heat indicator of the corresponding zone will display “H” until the zone has cooled to a safe temperature.

We're on Socials!

 @esatto.house  @esatto.house

www.esatto.house