


**esatto**


Ready to cook up a storm?  
Let's get started using this little  
**Quick Start Guide** to begin  
cooking with your **ECGG604W**  
60cm Gas on Glass Cooktop!



esatto

# Get ready to use your ECGG604W 60cm Gas on Glass Cooktop!

## Your Cooktop



- A Toughened Black Glass
- B Knob Controls
- C Cast Iron Trivets
- D Auxiliary Burner
- E Semi-Rapid Burner
- F Wok Burner

## Get in Touch

Need help? Contact our friendly support team via the contact details below.

Phone / 1300 11 4357

Email / [support@residentiagroup.com.au](mailto:support@residentiagroup.com.au)

## Product Details

Dimensions (W, D, H mm) / 600 × 510 × 100

Cut-out (A, B mm) / 560 × 490


Warranty / 2 Years

Register your Esatto product online for a free additional year [esatto.house/warranty](http://esatto.house/warranty)



## How to ignite the burners

- 1 Press in the control knob of the burner that you wish to light and turn it anti-clockwise towards the ignition symbol.
- 2 If you keep the control knob depressed, the automatic ignition for the burner will operate.
- 3 Then adjust the knob between positions 1 & 9 to your required flame intensity.
- 4 Once you have finished using the burner, ensure the knob is positioned upwards, with the indicator on the knob aligned to the Off knob control position.

## Knob Controls



## We're on Socials!

 @esatto.house  @esatto.house

[www.esatto.house](http://www.esatto.house)