

**esatto**


This little **Quick Start Guide** is everything you need to start capturing cooking odours & steam using your brand new **ERF60W 60cm Fixed Rangehood!**



# esatto

## Get ready to use your ERF60W 60cm Fixed Rangehood!

### The Controls



#### 1 Power Button

Press this button to turn off the fan.

#### 2 Low Fan Speed Button

Suitable for simmering and cooking without much steam.

#### 3 Medium Fan Speed Button

Ideal fan speed for regular cooking.

#### 4 High Fan Speed Button

Use this fan speed for heavy smoke or steam to achieve the maximum exhaust efficiency.

#### 5 Light Button

Press this button to turn the light on and off.

For a complete guide on operating your rangehood, refer to page 14 of your user manual.

### Get in Touch

Need help? Contact our friendly support team via the contact details below.

Phone / 1300 11 4357

Email / [support@residentiagroup.com.au](mailto:support@residentiagroup.com.au)

### Product Details

Dimensions (W, D, H mm) / 597 × 500 × 150

Extraction / 300m<sup>3</sup>/hr

Warranty / 2 Years

Register your Esatto product online for a free additional year [esatto.house/warranty](http://esatto.house/warranty)


### Installation & First Use

Before installing your new 60cm Fixed Rangehood, please ensure you have read all safety instructions in the user manual.

The typical installation method for your fixed rangehood is into a purpose built cupboard or by wall mounting.

Please refer to the dimensions of your rangehood shown in the diagram below.

#### Dimensions



When positioning the rangehood for installation and use, we advise that the rangehood is mounted at a height of between 650mm–750mm above the cooking surface for safety and performance of your rangehood.

For a complete installation guide, refer to user manual pages 10–13.

### We're on Socials!

@esatto.house @esatto.house

[www.esatto.house](http://www.esatto.house)