

Esatto
162L Upright Freezer
Model: EUF172S

Here is a little **Quick Start Guide** so you can start chilling with your new Esatto Upright Freezer—exactly what you need!



Esatto

162L Upright Freezer

Model: EUF172S

Ready? Let's get started.

The Thermostat Controls

Your fridge has one control for regulating the temperature. The temperature control is located on the front of the freezer above the cavity, visible only when the door is open. Depending on your room's ambient temperature, you may need to adjust the temperature setting to achieve your desired temperature.

The dial positions and related temperatures are as follows;

- Dial position "Min" provides a cool temperature at approximately -12°C.
- Dial position "Med" is suitable for normal operation approximately -15°C.
- Dial position "Max" provides the coolest temperature approximately -20°C.

Your Upright Freezer

1. Thermostat
2. Transparent Drawers
3. Flip Down Compartments
4. Adjustable Foot



Installation Tips

- When starting up for the first time, keep the freezer upright for 2 hours before connecting it to a power supply.
- When you install your appliance, set the thermostat knob to position "Med" for the first 24–48 hours, after which you can set it to the level that best suits your needs. It is the best to wait 24 hours before adding food.

Please refer to your user manual pages 9–10 for detailed instructions.

Get in touch

Need help? Contact our friendly support team via the contact details below.

Phone / **1300 11 4357**

Email / support@residentiagroup.com.au

How was your Esatto experience?

Share your story at esatto.house/review

We're on socials!

 @esatto.house

 @esatto.house

Product Details

Size (mm) / **550W x 550D x 1420H**

Energy Rating / **3.5 Stars**

Warranty / **2 Years**