

Product:

Air Purifier

Model Code/s:

EPUR200UVW

esatto

everything you
need is in this
user manual

Version:

V1.3 0622

Online:

esatto.house

esatto
everything
you need

Contents

Page 5
Welcome

Page 6
**General Safety
Instructions**

Page 8
Product Overview

Page 10
**Installation
Instructions**

Page 11
**Operation
Instructions**

Page 12
**Maintenance
& Cleaning**

Page 14
Specification

Page 15
Purchase Details

Page 16
Warranty

THIS PAGE HAS BEEN LEFT
INTENTIONALLY BLANK

Welcome

Residentia Group

—

Head Office

165 Barkly Avenue
Burnley, Victoria
Australia 3121

—

ACN

600 546 656

—

Online

residentia.group
www.esatto.house

Facebook @esatto.house

—

Postage

PO Box 5177
Burnley, Victoria
Australia 3121

—

Telephone

1300 11 4357

Congratulations on purchasing your new Air Purifier. The Esatto brand is proudly distributed within Australia by Residentia Group Pty Ltd.

Please refer to the warranty card at the rear of this manual for information regarding your product's parts and labour warranty, or visit us online at: www.residentia.group

At Residentia Group, we are customer obsessed and our Support Team are there to ensure you get the most out of your appliance. Should you want to learn more about your new appliance, it's features or importantly taking care of the appliance, our Support Team are here to help.

You can use our online Support Centre at anytime by visiting:
<http://support.residentiagroup.com.au>

Or you can contact us via phone by dialing: 1300 11 HELP (4357).

It is important that you read through the following use and care manual thoroughly to familiarise yourself with the installation and operation requirements of your appliance to ensure optimum performance.

Again, thank you for choosing an Esatto appliance and we look forward to being of service to you.

Kind Regards,
The Residentia Team



General Safety Instructions

IMPORTANT SAFETY INSTRUCTIONS READ CAREFULLY AND KEEP FOR FUTURE REFERENCE

Read this manual thoroughly before first use, even if you are familiar with this type of product. The safety precautions enclosed herein reduce the risk of fire, electric shock and injury when correctly adhered to. Make sure you understand all instructions and warnings.

Keep the manual in a safe place for future reference, along with the completed warranty card and purchase receipt. If you sell or transfer ownership of this product, pass on these instructions to the new owner.

Always follow basic safety precautions and accident prevention measures when using an electrical appliance, including the following:

IMPORTANT: Pay particular attention to messages that contain the words **DANGER, WARNING** or **CAUTION**. These words are used to alert you to a potential hazard that can seriously injure you and others. The instructions will tell you how to reduce the chance of injury and let you know what can happen if the instructions are not followed.

USAGE CONDITIONS AND RESTRICTIONS

- **Domestic use only:** This appliance is intended for indoor household use only. It is not intended for commercial, industrial or outdoor use. It is not intended for use in a recreational vehicle.
- **Purpose:** Do not use this appliance for anything other than its intended purpose. Other uses are not recommended and may cause fire, electric shock or personal injury.
- **Attachments:** The use of attachments is not recommended by the appliance manufacturer and distributor as they may be hazardous.
- **Improper use:** Damage due to improper use, or repairs made by unqualified personnel will void your warranty. We assume no liability for any eventual damages caused by misuse of the product or noncompliance with these instructions.


WARNING:

- When the appliance is not in use and before cleaning, unplug the appliance from the outlet.
- To protect against the risk of electrical shock, do not immerse the unit, cord or plug in water or other liquid.
- Do not place other items on top of the appliance, and do not sit or stand on this appliance.
- Please use the original filter provided by the factory. In case of other filters, the best results cannot be achieved.
- Do not insert the fingers or objects into the air inlets or air outlets to prevent the product from physical damages or malfunction.
- Please unplug the power cord immediately and contact the service center in time when the appliance suffers abnormal sound or burnt smell or smoke.
- Do not spray flammable substances near the appliance; Do not spray water directly on the appliance or use chemical cleaners like alcohol or hydrochloric acid, etc.; Do not place water containers, medicines, or flammable materials on the appliance.
- Do not block the air inlets/outlets of the appliance with any item.
- This appliance cannot replace natural ventilation and other appliances like the vacuum cleaner, kitchen ventilator, etc.
- When the appliance is working, it must be placed on a dry, flat and stable floor, with at least 30cm space reserved around it.
- Do not put it in a place with direct sunlight.
- To prevent electromagnetic disturbance, the appliance must keep a certain distance from the TV, radio, microwave oven and others.
- Do not disassemble or modify this appliance without authorisation to avoid accidents.
- Do not pull the adapter cable to move the appliance.
- **WARNING:** To reduce the risk of fire or electric shock, do not use this fan with any solid-state speed control device.
- Prior to cleaning or other maintenance, the appliance must be disconnected from the supply mains.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- If the supply cord is damaged, it must be replaced by a special cord or assembly available from the manufacturer or its service agent.
- This appliance is only to be used with the power supply unit provided.
- Children should be supervised to ensure that they do not play with the appliance.
- This appliance contains a UV-C emitter.
- Unintended use of the appliance or damage to the housing may result in the escape of dangerous UV-C radiation. UV-C radiation may, even in little doses, cause harm to the eyes and skin
- Appliances that are obviously damaged must not be operated.
- The appliance can't be replaced by user.



The appliance must not be disposed of with regular household waste. At the end of its service life, the appliance must be properly delivered to a collection point for the recycling of electrical and electronic equipment. By Collection and recycling of old appliances, you are making an important contribution to the conservation of our natural resources and provide for environmentally sound and healthy disposal.

Product Overview



- Key:
1. Operation panel/Display screen
 2. Air outlet grille
 3. Back cover plate
 4. Adapter cable
 5. HEPA filter
 6. Base plate

- Not shown but also included:
- 1 × Instruction manual
 - 1 × Quick Start Guide
 - 1 × Protective bag

Note: The images in this user manual are for reference only. Your appliance may appear differently.

CONTROL PANEL



1. **UV Light Button**
Press this button to turn on the UV light.
Press and hold this button for 3 seconds to reset the filter warning.
2. **Mode Button**
Press the Mode button to alternate the function mode between Turbo, Sleep and Auto mode.
3. **On/Standby Button**

DISPLAY SCREEN








4. **UV Light indicator**
5. **Turbo mode indicator**
6. **Sleep mode indicator**
7. **Auto mode indicator**
8. **HEPA filter replacement indicator**
9. **Air Quality indicator**

Note: The images in this user manual are for reference only. Your appliance may appear differently.

Installation Instructions

INSTALLATION STEPS

- 1 Remove the base plate
- 2 Take out the HEPA filter
- 3 Remove the protective film of the filter assembly
- 4 Install the HEPA filter
- 5 Install the base plate
- 6 Plug in adapter cable
- 7 Plug power supply








Operation Instructions

NOTE:

- Should you like to keep your appliance connected to a power source continuously, please enter the operational mode before the standby state after each power on.
- If an unexpected power outage has occurs (eg. when the power is off or the power cord is unplugged during normal operation), the previous state will resume when the power is restored to the appliance.

BEFORE FIRST TIME USE:

- 1 Remove the protective film of the filter assembly.
 - 2 Install the filter
 - 3 Power on for the first time, the display panel flashes for 1s, and then the screen is turned off. The whole appliance is the standby state;
 - 4 On/Standby: Press the On/Standby button
 - 5 Operation: The purifier is powered on for the first time and then enters the Turbo mode.
- Note: This model is equipped with a memory function and will enter the mode that was last used.*




Maintenance & Cleaning

NOTE:



Be sure to turn off the appliance and remove the plug before any maintenance is performed.

BODY CLEANING**Exterior**


Wipe the body with a soft towel.

**INSIDE THE MACHINE HOUSING**

Open the base plate, vacuum up dust with a vacuum cleaner or wipe it with a cloth.

**AIR OUTLET GRILLE**

Vacuum up dust with a vacuum cleaner or wipe it with a cloth.




CLEANING OF THE HEPA FILTER

It is recommended to clean the HEPA filter at least once every two weeks.


The cleaning cycle can be based on the usage environment and time, seriously polluted environment should be cleaned frequently.

- 1 Unplug the appliance, and take out the HEPA-filter.
- 2 Vacuum the dust or wipe it with a dry cloth or vacuum.
- 3 Assemble the HEPA-filter
- 4 Plug in the appliance, and start it.



REPLACEMENT OF THE FILTER COMPONENTS

- 1 Filter model: FH-20Z1 (1 × included).
- 2 When the red light indicator is on, it is to remind you that the HEPA filter should be replaced. If it is not replaced in time, the prompt will appear after every startup.
- 3 Replace a new filter.
- 4 Long press the UV Light button for 3 seconds to reset the HEPA filter.



Specifications

Model:	EPUR200UVW
High-grade CADR_{particles}	250
Product Dimensions (W, D, H):	240mm, 240mm, 382mm
Net Weight:	2.8kg
Input Voltage (V):	24V [~]
Rated Power (W):	22
Max Noise Rating:	55dB(A)

Purchase Details

For your records, please record details of your purchase below and staple your receipt on this page.

Your serial number can be found on the rear of your Air Purifier.

STORE DETAILS

STORE NAME |

ADDRESS |

TELEPHONE |

PURCHASE DATE |

PRODUCT DETAILS

MODEL NO. |

SERIAL NO.* |

Warranty

WARRANTY TERMS AND CONDITIONS AIR PURIFIERS

This document sets out the terms and conditions of the product warranties for Residentia Group Appliances. It is an important document. Please keep it with your proof of purchase documents in a safe place for future reference should you require service for your Appliance.

1. **IN THIS WARRANTY**
 - (a) 'acceptable quality' as referred to in clause 10 of this warranty has the same meaning referred to in the ACL;
 - (b) 'ACL' means Trade Practices Amendment (Australian Consumer Law) Act (No.2) 2010;
 - (c) 'Appliance' means any Residentia Group product purchased by you accompanied by this document;
 - (d) 'ASR' means Residentia Group authorised service representative;
 - (e) 'Residentia Group' means Residentia Group Pty Ltd of 165 Barkly Ave, Burnley VIC 3121, ACN 600 546 656 in respect of Appliances purchased in Australia;
 - (f) 'major failure' as referred to in clause 10 of this warranty has the same meaning referred to in the ACL and includes a situation when an Appliance cannot be repaired or it is uneconomic for Residentia Group, at its discretion, to repair an Appliance during the Warranty Period;
 - (g) 'Warranty Period' means:
 - (i) where the Appliance is used for personal, domestic or household use (i.e. normal single family use) as set out in the instruction manual, the Appliance is warranted against manufacturing defects for 24 months, following the date of original purchase of the Appliance;
 - (h) 'you' means the purchaser of the Appliance not having purchased the Appliance for re-sale, and 'your' has a corresponding meaning.
2. This warranty only applies to Appliances purchased and used in Australia and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia.
3. During the Warranty Period Residentia Group or its ASR will, at no extra charge if your Appliance is readily accessible for service, without special equipment and subject to these terms and conditions, repair or replace any parts which it considers to be defective. Residentia Group or its ASR may use remanufactured parts to repair your Appliance. You agree that any replaced Appliances or parts become the property of Residentia Group. This warranty does not apply to light globes, batteries, filters, seals or similar perishable parts.
4. Parts and Appliances not supplied by Residentia Group are not covered by this warranty.

5. You will bear the cost of transportation, travel and delivery of the Appliance to and from Residentia Group or its ASR. If you reside outside of the service area, you will bear the cost of:
 - (a) travel of an authorised representative;
 - (b) transportation and delivery of the Appliance to and from Residentia Group or its ASR, in all instances, unless the Appliance is transported by Residentia Group or its ASR, the Appliance is transported at the owner's cost and risk while in transit to and from Residentia Group or its ASR.
6. Proof of purchase is required before you can make a claim under this warranty.
7. You may not make a claim under this warranty unless the defect claimed is due to faulty or defective parts or workmanship. Residentia Group is not liable in the following situations (which are not exhaustive):
 - (a) the Appliance is damaged by:
 - (i) accident
 - (ii) misuse or abuse, including failure to properly maintain or service
 - (iii) normal wear and tear
 - (iv) power surges, electrical storm damage or incorrect power supply
 - (v) incomplete or improper installation
 - (vi) incorrect, improper or inappropriate operation
 - (vii) insect or vermin infestation
 - (viii) failure to comply with any additional instructions supplied with the Appliance;
 - (b) the Appliance is modified without authority from Residentia Group in writing;
 - (c) the Appliance's serial number or warranty seal has been removed or defaced;
 - (d) the Appliance was serviced or repaired by anyone other than Residentia Group, an authorised repairer or ASR.
8. This warranty, the contract to which it relates and the relationship between you and Residentia Group are governed by the law applicable where the Appliance was purchased.
9. To the extent permitted by law, Residentia Group excludes all warranties and liabilities (other than as contained in this document) including liability for any loss or damage whether direct or indirect arising from your purchase, use or non use of the Appliance.
10. For Appliances and services provided by Residentia Group in Australia, the Appliances come with a guarantee by Residentia Group that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the Appliance repaired or replaced if the Appliance fails to be of acceptable quality and the failure does not amount to a major failure. The benefits to you given by this warranty are in addition to your other rights and remedies under a law in relation to the Appliances or services to which the warranty relates.
11. At all times during the Warranty Period, Residentia Group shall, at its discretion, determine whether repair, replacement or refund will apply if an Appliance has a valid warranty claim applicable to it.
12. Missing parts are not covered by warranty. Residentia Group reserves the right to assess each request for missing parts in a case by case basis. Any parts that are not reported missing in the first week after purchase will not provide free of charge.
13. To enquire about claiming under this warranty, please follow these steps:
 - (a) carefully check the operating instructions, user manual and the terms of this warranty;
 - (b) have the model and serial number of the Appliance available;
 - (c) have the proof of purchase (e.g. an invoice) available;
 - (d) telephone the numbers shown below.
14. You accept that if you make a warranty claim, Residentia Group and its ASR may exchange information in relation to you to enable Residentia Group to meet its obligations under this warranty.

IMPORTANT

Before calling for service, please ensure that the steps in point 12 have been followed.

CONTACT SERVICE

- Service: 1300 11 HELP (4357)
- Spare parts: 1300 11 SPARE (7727)



E2447

esatto everything you need



A RESIDENTIA
GROUP INITIATIVE